

Delime & Descale Your Dish Machine

1. Remove dish machine detergents from the dispensers
2. Fill dish machine with clean water
3. Hot Water Dish Machines:
 - Single tank dish machines can run on manual timer for 10 minutes
 - Conveyor dish machines can run on automatic or manual for 10 minutesLow Temp Dish Machines: Have a delimer switch on the control panel
 - Turn switch to the right for delimer mode
 - Run dish machine for 10 minutes
 - Turn switch back to automatic
4. Pour 1/3 gallon of delimer into dish machine and run for 10 minutes (This is a great time to run coffee cups through the machine to remove stains. You can also process glasses that have hazing from mineral build up).
5. Drain dish machine of all delimer/descaler and fill with fresh water
6. Reconnect all chemicals to dispensers and run dish machine



IMPORTANT: All cups/glasses that were processed with delimer must go through the dish machine once chemicals are reconnected.

AVAILABLE IN 3 STRENGTHS - In stock and ready for delivery!



#20262 Medium
Strength Delimer
Descaler



#20282 Extra Strength
3-D



#21171 Green Certified
Scale Safe (DFE)